

RECMAR *Products*

Phone (800) 793-9611 FAX (713) 944-4809 www.recmar.com

Installation Instructions – 3292 Track

1. Purchase appropriate mounting screws and anchors as needed (not provided). Hardware required varies depending on ceiling construction.
2. Cut track to length. Any miter saw or hack saw will easily cut the track. Consider centering the seam if splicing tracks together and be sure each cut is a clean perpendicular cut and any burrs are removed.
3. Identify optimal location to screw 3080 snap in retainer catch into ceiling or wall. It is preferred to drive mounting screws into ceiling joists, wall studs or other solid supports. Anchors may be required if mounting directly to sheetrock. Holes should be spaced 18-24 inches apart.
4. Mark screw locations on the ceiling or wall to identify where to drill mounting holes. Be sure to align these holes correctly.
5. Using an appropriately sized drill bit, drill pilot holes into the ceiling or wall.
6. Use screws to mount the brackets onto the ceiling or wall by driving screws through the holes in the retainer catches and into the predrilled holes.
7. Snap the track into place once catches are fully mounted to the ceiling or wall by pushing the wider portion of the track into the snap in retainer catches with significant pressure.
8. Slip the carrier heads into the end of the track with the body of the carrier projecting through the slot in the track.
9. Insert an end stop into the slot. For 3030 end stops, position with the square nut above the slot, inside the track, with the head of the screw outside the slot. For 3032 end stops, position the loop perpendicular to the slot. Tighten the screw with a screw driver to lock the end stop into place.

