

# **RECMAR** *Products*

Phone (800) 793-9611 FAX (713) 944-4809 [www.recmar.com](http://www.recmar.com)

## **Wall Mount Installation Instructions – 84003 Track**

1. Measure track lengths required and cut to length. Standard miter saw or hack saw work fine with no special blade required. If splicing tracks together end to end, be sure that the cut is made cleanly at a square 90 degree angle to the track and that all burrs are removed.

***Hint: Consider leaving at least a one inch gap between the end of the track and the wall on one end to allow for carriers to be added or removed without having to take down the entire track.***

2. Identify where the mounting brackets are best mounted to the wall. Spacing between brackets should be 24-48 inches. Recommend spacing of no more than 24 inches where draperies will be stacked when opened. 48 inch spacing is acceptable across the rest of the span for moderate weight curtains. Whenever possible, align wall brackets with wall studs. Anchors will be required if studs are not available. When splicing tracks together, consider the location of the splicer so as not interfere with the location of your wall brackets.

***Hint: Be sure to mount the wall brackets level across the wall – this is greatly aided by the use of a laser level***

3. Drill pilot holes for wall bracket mounting screws (not provided), then mount the brackets on the wall using appropriate screws.

4. Adjust position of the mounting clip on each wall bracket so it provides adequate and consistent clearance for the draperies by loosening and tightening the set screw as needed.

5. Insert carriers into the end of the track with the narrow section hanging downward through the slot in the track.

6. If splicing tracks together, loosen the set screws on the 84142 splicer. Slide the end of one track into the splicer so that the dog ears on top of the track are locked into place halfway across the splicer. Tighten the set screws. Slide the end of the other track into the other end of the splicer so that the tracks abut one another, and tighten the remaining set screws. The splicer will sit on top of the track after it is mounted.

7. Secure end stops at each end of the track by loosening the set screw, and sliding the end stop into the slot from the end of the track with the metal base below the track and the nut on the screw above the slot, inside the track. Position the flange that points down away from the wall – this lets you easily insert a drapery pin hook to anchor the end of the curtain to the end of the track. (If using 7127 end stops, place the nut above the slot inside the track and the head of the screw below the track).

8. Position the track under the wall bracket overhang so that the outer dog ear on the top of the track is wedged into the notch on the out edge of the mounting clip. Use a screw driver to turn the cam held in place by the set screw 90 degrees until the track is locked into place. Repeat at each wall bracket.

9. Attach the curtain to the carriers using the appropriate method for the given carrier (e.g. drapery pin hook or snap tape into carriers).