

# RECMAR *Products*

## 6100 Flexible Track, Drop-Ceiling Installation Instructions

### Use Caution When Releasing Coiled Track– Track May Snap Open

- Tools Needed: Screw Driver, Pliers, Drill, Hacksaw
- Mounting Screws are not included. For Drop-Ceiling mounts, the 6155 Drop-Ceiling Clamp and the 6151 Ceiling Cartridge will attach together by removing the screw in the drop-ceiling clamp and putting it up through the hole in the ceiling cartridge. Put the clamp back together on the ceiling cartridge.
- Attach drop ceiling clamp to the T-grid strip, tighten the clamp on the grid and tighten the screw to hold in place.



- The track will be easier to handle if the track is straightened before it is put in the cartridges. Cut track to length with a hack saw one inch less than the length of the mounting line to allow space for end caps. Starting at one end, place the track in the cartridges in sequence, locking the cartridges over the track, (use pliers if necessary). The flat side of the track will mount toward the ceiling. If a curve or bend is desired, the track will easily curve as you place it into the cartridges.



- If you are using the 7142 hook to attach your curtain, put the hooks on the carriers and squeeze the top closed with pliers to attach the hook permanently.
- End caps and carries can be placed on the track after it is installed on the ceiling. End caps are pressed onto the end of the track and the mounting screw is tightened.

**For questions or technical support, contact RECMAR Products at 713-944-4885 or email at [service@recmar.com](mailto:service@recmar.com).**